

RHYTHM MACHINE&MODULE

AKAI		XtremeLead1		MC303		RM50	
XE8		BD	30	BD	20	BD	50
PRESET	20	CYMBAL	17	BELL	9	Cymbal	22
XR10		HH	39	CLAP	11	HiHat	18
DRUMS	54	PERC	68	CYMBAL	7	Perc	41
ALESIS		RIM	7	HH	19	Rim	4
D4		SD	50	PERC	53	SD	50
BD	35	Procussion		SD	39	TOM	49
CYM	25	BASS WAVE	4	TOM	6	RX5	
HH	30	BD	12	MC505		DRUMS	52
PERC	39	CYM	8	BD	40	RX5_CARD	
RIM	2	HIHAT	10	CLAP	8	WRC04	19
SD	35	PERC	65	CYMBAL	9	RX7	
TOM	29	RIM	3	HIHAT	54	BASS&GUITAR	8
HR16		SD	23	PERC	48	BD	9
DRUMS	49	TOM	6	RIM	8	HH&CYMBAL	8
HR16B		Vintage Keys		SD	40	PERC	26
DRUMS	47	DRUMS	20	TOM	26	SD&RIM	9
BOSS		Ensoniq		R8		TOM	10
DR55		SD1		BD	9	RX8	
DR55_BD	11	DRUMS	44	CLAP	1	DRUMS	43
DR55_HH	11	HAMMOND		Cymbal	5	RX11	
DR55_RS	11	DPM48		EFF	2	DRUMS	29
DR55_SD	11	DRUMS	22	Hihat	3	RX17	
DR202		KAWAI		Perc	20	DRUMS	26
DR202_BD	16	R50		Rim	2	RX21	
DR202_SD	25	DRUMS	24	SD	12	DRUMS	9
DR202_HH_CYM	17	R50e		TOM	13	RX21L	
DR202_RIM_CLAP_SNAP_TOM	18	DRUMS	33	MT32		DRUMS	16
DR202_PERCS	30	R100		DRUMS	53	RX120	
DR220A		DRUMS	24	TR55		DRUMS	38
DRUMS	11	KORG		DRUMS	9	RY9	
DR220E		DDD1 PRESET		TR66		BD	14
DRUMS	11	DRUMS	18	DRUMS	13	Cymbal	6
DR550		T1		TR77		HiHat	8
DRUMS	48	BD	7	DRUMS	12	Perc	43
DR550MK11		CYM	4	TR505		RIM	3
BD	11	HIHAT	7	DRUMS	16	SD	24
CLAP	2	PERC	23	TR606		TOM	30
CYMBAL	4	RIM STICK	3	DRUMS	13	RY20	
HIHAT	7	SD	9	TR626		BD	34
MISC	3	TOM	12	DRUMS	30	CYMBAL	20
PERC	29	DDD5		TR707		HIHAT	11
RIM	2	DRUMS	29	DRUMS	15	PERC	37
SD	18	DDM110		TR727		RIM	2
TOM	15	DRUMS	9	DRUMS	15	SD	49
DR660		DDM220		TR808		TOM	16
DR660_BD	25	DRUMS	9	TR808 CONGA	18	RY30 PRESET	
DR660_SD	30	KR33		TR808_BD	30	RY30_BD	7
DR660_RIM_HH	30	DRUMS	13	TR808_CYM	36	RY30_SD	10
DR660_CYM	12	KR55		TR808_HH	7	RY30_RIM	2
DR660_TOM	24	DRUMS	9	TR808_PERC	5	RY30_HH	8
DR660_PERC_BASS	32	M1		TR808_SD	36	RY30_CYM	5
DR670		DRUMS	34	TR808_TOM	18	RY30_TOM	8
DR670_BD	30	Linn		TR909		RY30_PERC	20
DR670_SD	60	LINN9000		TR909_BD	13	RY30 WAVES	7
DR670_HH	36	DRUMS	17	TR909_HH_PERC	16	SY35	
DR670_CYM	25	LM1		TR909_SD	27	DRUMS	21
DR670_STICK_TOM	25	DRUMS	14	TR909_TOM	24	SY99	
DR670_PERC	44	MFB		Sequential Circuits		DRUMS	50
JS5		model512		DrumTraks		TG55	
JS5_BD	16	DRUMS	9	DRUMS	96	DRUMS	27
JS5_BRUSH	9	Oberheim		TOM		TG500	
JS5_CLAP	2	DMX		DRUMS	8	BD	8
JS5_CYMBAL	6	DRUMS	17	Simmons		CYMBAL	3
JS5_HIHAT	6	DX		SDS5		HIHAT	7
JS5_MISC	14	DRUMS	9	DRUMS	23	MISC	9
JS5_PERC	35	Pearl		YAMAHA		PERC	28
JS5_RIM	2	SC40		CS6X		RIM	1
JS5_SD	19	BD	16	BD	12	SD	9
JS5_TOM	18	CLAP	2	Cymbal	8	TOM	2
CASIO		Cymbal	5	Hihat	10	ZOOM	
RZ1		HiHat	2	Perc	35	RT123	
DRUMS	12	Perc	20	Rim	3	BD	14
PT30		SD	3	SD	26	CALP	1
DRUMS	6	TOM	26	T8	19	CYMBAL	6
COLUMBIA		ROLAND		T9	20	HIHAT	6
CRB102		CR68		TOM	10	PERC	24
DRUMS	8	DRUMS	13	MR10		RIM	3
DOEPFFER		CR78		BD	1	SD	10
MS404		DRUMS	20	CYMBAL	6	TOM	9
BD	18	CR5000		HITOM	6	RT234	
HiHat	7	DRUMS	20	LOTOM	6	BD	12
Perc	13	D20		SD	6	CYMBAL	5
RIM	1	DRUMS	54	RM1X		HH	8
SD	4	D70		BD	24	PERC	26
TOM	3	DRUMS	58	CLAP	6	RIM	3
EMU		JV880		CYMBAL	20	SD	16
Drumulator		BD	6	ETHNIC	42	TOM	12
DRUMS	12	Cymbal	3	HIHAT	26	NB	
MORPHEUS		HiHat	3	PERC	43	RHYTHM BOX TS2000	
BD	10	Perc	27	RIM	8	DRUMS	5
HiHat	16	SD_RIM	7	SD	29		
MISC	10	TOM	4	TOM	29		
PERC	19						
RIM	4						
SD	14						