

RHYTHM MACHINE/MODULE					
AKA1					
96/24 XEB	96/24 COLUMBIA	96/24 KR55	96/24 SD-PCOM1_3	96/24 RY10	
PRESET	20 DRUMS	8/96/24 M1	DRUMS	9	BD
SLDRIBRY SET	DOFFER	DRUMS	34	HiHat	5
SLDR2R(AMBLENCE SET)	96/24 NS404	96/24 M3	Perc	2	CYMBAL
SLDR3R(LK AMBLENCE SET)	15	BD	30	14	PERC
96/24 XRT0	HiHat	7	CLAP	2	RIM
DRUMS	54 Perc	13	CYMBAL	12	SD
ALESIS	RIM	1	FXPERC	25	TOM
96/24 D4	SD	4	HiHat	6	TR55
BD	TOM	3	KEY	27	DRUMS
CYM	96/24 SMI	Perc	47/96/24 TR65	96/24 RY20	BD
FX	75 Drumulator	RIM	2	DRUMS	13
HI	30 DRUMS	12	SD	22	96/24 TR77
PERC	75/96/24 MORPHEUS	Ton	23	DRUMS	12
RIM	4	BD	17	Linn	96/24 TR505
SD	95	HiHat	28	LINNWOOD	DRUMS
TOM	92	MISC	10	DRUMS	17
96/24 HR16	PERC	32	LM1	96/24 TR65	SD
DRUMS	49	RIM	4	DRUMS	14
96/24 HR16B	SD	24	96/24 LM2	DRUMS	30
DRUMS	47	96/24 XtremeLead1	DRUMS	27	96/24 TR707
96/24 GSS_1	BD	57	MFB	DRUMS	15
BD	15	CYMBAL	17	mode1512	96/24 TR127
Cymbal	14	HI	39	DRUMS	9
FX	17	MISC	54	MEX	96/24 TR65
HiHat	23	PERC	115	Computer Rhythm 185	96/24 TR65
Perc	73	RIM	7	DRUMS	12
RIM	4	SD	92	Oberheim	TR808_BD
SD	16	96/24 Procussion	DMX	TR808_HI	12
TOM	24	BASS WAVE	4	DRUMS	17
BOSS	BD	12	DM	TR808_PERC	5
96/24 DRS	CYM	6	DRUMS	9	TR808_SD
DRS_BD	32	HiHAT	10	Pearl	96/24 TR909
DRS_Cymbal	7	PERC	73	96/24 SC40	TR909_BD
DRS_FX	20	RIM	3	BD	18
DRS_HiHat	10	SD	23	CLAP	2
DRS_Perc	37	TOM	6	Cymbal	5
DRS_Rim	7	NAHES	81	HiHat	2
DRS_SD	40	96/24 Vintage Keys	Perc	20	96/24 Sequential Circuits
DRS_Tom	26	DRUMS	20	SD	3
96/24 DR55	Ensoniq	TOM	26	TOM	DRUMS
DR55_BD	11	SD1	ROLAND	DRUMS	8
DR55_HI	11	DRUMS	44	CR69	96/24 RSC001
DR55_RS	11	HAMMOND	DRUMS	13	SOSS
DR55_SD	11	DRUMS	47/8	DRUMS	38
96/24 DR202	DRUMS	22	DRUMS	20	YAMAHA
DR202_BD	31	96/24 DPW46E	96/24 DR5000	96/24 CSXA	96/24 SY77
DR202_SD	49	DRUMS	22	DRUMS	20
DR202_HI_CYM	31	KAWAI	96/24 B20	Cymbal	8
DR202_RIM_CLAP_SNAP_TOM	33	96/24 R50	DRUMS	54	FX
DR202_PERCS	62	DRUMS	24	D70	HiHat
96/24 DR228A	DRUMS	11	DRUMS	58	Perc
DRUMS	11	DRUMS	33	96/24 JD990	Rim
96/24 DR220E	96/24 RS011	DRUMS	80	SD	26
DRUMS	11	Acoustic Kit	24	96/24 JV880	T8
96/24 DR550	Electric Kit	24	BD	6	T9
DRUMS	48	Jazz Latin Kit	24	Cymbal	3
96/24 DR550K11	96/24 R100	HiHat	3	96/24 M810	RIM
BD	11	DRUMS	24	MISC	40
CLAP	2	KORG	DRUMS	27	CYMBAL
CYMBAL	4	96/24 OT/W	SD_RIM	7	HITOM
HiHAT	7	DRUMS	86	TOM	4
MISC	3	96/24 D001 PRESET	96/24 MC303	SD	11
PERC	29	DRUMS	18	BD	20
RIM	2	96/24 D001 CARD	BELL	9	BD
SD	18	BRUSH	4	CLAP	11
TOM	15	CYMBAL1	2	CYMBAL	7
96/24 DR660	CYMBAL2	2	HI	19	ETHRIC
DR660_BD	51	E_DRUMS1	6	HIT	26
DR660_SD	72	E_DRUMS2	6	PERC	53
DR660_RIM_HI	48	FUSION1	4	SD	39
DR660_CYM	19	FUSION2	5	TOM	6
DR660_TOM	39	GAMECAH	4	96/24 M850S	SFX
DR660_PERC_BASS	70	GATEREVERB1	6	BD	67
96/24 DR670	GATEREVERB2	6	CLAP	8	96/24 R860
DR670_BD	52	GATEREVERB4	5	CYMBAL	9
DR670_SD	61	HAND CLAPS	HiHat	54	Cymbal
DR670_HI	107	8FINGER SNAPS	8	MISC	84
DR670_CYM	85	ISHIBASHI	8	PERC	48
DR670_STICK_TOM	39	JAZZ1	6	RIM	8
DR670_PERC	76	LATIN1	8	SD	87
DR670_FX	92	LATIN2	8	TOM	26
96/24 DrPad DRP1	LATIN3	7	96/24 M132	TOM	107
CYMBAL	6	LATIN4	5	DRUMS	53
HandClap	6	LATINS	7	96/24 PB300 RhythPlus	DRUMS
SnareDrum1	6	ORCHESTRAT2	3	DRUMS	24
SnareDrum2	6	ROCK	8	96/24 RB	MRO22
Tambourine	6	ROCK1	5	PRESET	MRO23
Timpani	6	ROCK2	6	BD	9
96/24 DrPad DRP3	ROCK3	5	CLAP	1	96/24 R07
COMBEL	6	ROCK4	6	Cymbal	5
GONG_L	6	SNARE DRUM 1	4	EFF	2
GUT JACK	6	SNARE DRUM 2	4	HiHat	3
SHAKING_GLASS	6	TOM1	5	Perc	26
SCRATCH	6	VARIATION1	4	Rim	2
TINBALL	6	VARIATION2	6	SD	12
96/24 JSS	96/24 T1	TOM	13	96/24 R08	DRUMS
JSS_BD	16	BD	7	EDIT	DRUMS
JSS_BRUSH	9	CYM	4	BD	17
JSS_CLAP	2	HiHAT	7	CLAP	2
JSS_CYMBAL	6	PERC	34	Cymbal	10
JSS_HiHAT	6	RIM STICK	3	HiHat	10
JSS_MISC	14	SD	9	Perc	14
JSS_PERC	50	TOM	12	Rim	2
JSS_RIM	2	96/24 S3	SD	22	96/24 R021L
JSS_SD	19	DRUM WAVE	70	TOM	30
JSS_TOM	29	KIT	165	PCM SOUND CARD	96/24 R020
96/24 CAS10	DRUMS	29	SN_RS_01	25	DRUMS
96/24 MA101	DRUMS	29	SN_RS_02	26	96/24 RY9
DRUMS	13	96/24 DM110	SN_RS_03	26	BD
96/24 RZ1	DRUMS	9	SN_RS_04	26	Cymbal
DRUMS	12	96/24 DM220	SN_RS_05	26	HiHat
96/24 P100	DRUMS	9	SN_RS_06	26	Perc
DRUMS	6	96/24 KR53	SN_RS_07	26	RIM
DRUMS	13	DRUMS	13	SN_RS_08	26
				SN_RS_09	26
				SN_RS_10	27
				SN_RS_11	26